


flow-captor 412x.52/.53/.73/.80/.81M - AC types Operating Instructions

Please read carefully: No liability can be accepted for damage caused by improper use of the captor



9.0 Protection cap

To protect the flow-captor from environmental influences and unintended adjustment the flow-captor comes with a screw cap. After adjustment of the flow-captor screw on the cap tiedly. So the O-ring will seal the flow-captor to get protection standard IP67



- a Sensor head of stainless steel WN 1.4305 (V2A, 303) (standard quality)
- b Sensing surface
- c Thread, G 1/2 A (1/2" BSP), alt. 1/2" – 14 NPT
- d Section for SW 27 spanner (wrench)
- e Housing, WN 1.4305 (V2A, 303)
- f Housing, front plate, anodized aluminium
- g Plug M 12x1, 4-pin
- i Display of 9 LED, functions:
Analog display of flow from 0 to 100%
Display of set-point by flashing LED, adjustable from 1. to 8. LED
- k Potentiometer for „Set-point“
- l LED for output indication „Flow-OK“
- m Potentiometer for "Range"

weber

flow-captor 412x.52/.53/.73/.80/.81M - AC types Operating Instructions

Please read carefully: No liability can be accepted for damage caused by improper use of the captor



1.0 Mounting Position

To obtain highest accuracy of switching signal, flow-captor should be mounted in a position of minimum turbulence. The position should be at least 5 x ID downstream and 3 x ID up-stream of bends, valves, T-pieces or changes in Pipe diameter.

Immersion depth min. 5 mm for small pipes up to 1 1/2 " ID.


Preferred position is in a vertical pipe with upward flow.

In a horizontal pipe, the flow-captor should be mounted at the side.

The sensor head orientation is independent from the flow direction.

For high temp. version, horizontal mounting for optimal cooling effect.

horizontal position of the unit →



2.0 Mechanical Installation

flow-captor should be installed into pipe at sufficient depth to ensure that the sensing surface is in contact with the flowing medium at all times. This is particularly important, if the flow-captor is mounted on top of the pipe or in a T-piece larger than the pipe work where cavitation (air bubbles) may occur.

flow-captor can be installed in a T-piece. However it is much better to install the unit in a fitting welded to the pipework.


Thread should be sealed with Teflon tape or other commercial sealer, then flow-captor tightened in the fitting using a size SW 27 spanner (wrench)

CAUTION: ON NO ACCOUNT SHOULD THE FLOW-CAPTOR HOUSING BE USED FOR TIGHTENING INTO THE PIPEWORK:

Final position should have the LED chain horizontal and reading left to right.

Storage conditions:

Just store in a dry and frost-free place. Ambient temperature should not be exceed 50°C (122°F).



weber

flow-captor 412x.52/.53/.73/.80/.81M - AC types

Operating Instructions

Please read carefully: No liability can be accepted for damage caused by improper use of the captor



3.0 Electrical Connection

Insert plug gently into unit socket (do not force as plug can only be mounted in correct way). Then tighten the plug connection by hand (that only ensures a sealing according to protection class IP67).

Connect wire end of the cable to power supply according to connection diagram.

The voltage must be kept within the specified range at all times 90-170 VAC (.52/.53), 90-250VAC/DC (.73) or 90-250 VAC (.80/.81)

Connect load at point 4 + 5 (relay contacts).

After connecting the supply voltage the 1st LED shines and one of the other 8 LED's is flashing (adjusted set-point).

After approx. 8 seconds the sensor is ready for operation (at zero flow only the 1st LED lights up).

4.0 Medium

Scale of range potentiometer on 4120.xxM is related to water. Depending on viscosity and thermal conductivity, other media require a multiplier (> 1) i. e. 3 to 5 x for oil.

4121.xxM is calibrated specifically for use with oil. The scale is equally divided between zero flow and max. flow range. The neutral scale 1 to 9 does not shows absolute values as these will vary with different types of oil.





5.0 Measurement of Flow Velocity (only 4120.5x/.8xM)

Turn range potentiometer clockwise to maximum (3 m/s).

According to the flow rate a number of LED's will be lit.

In order to read the correct flow rate, turn the range potentiometer slowly, stepwise, counter-clockwise – this allows for a re-adjustment of the range – until all LED's are lit.

Actual flow speed is indicated by a white arrow on the range pot.



flow-captor 412x.52/.53/.73/.80/.81M - AC types

Operating Instructions

Please read carefully: No liability can be accepted for damage caused by improper use of the captor




6.0 Range Adjustment

With the range potentiometer it is possible to define any measuring range between 0-20 cm/s up to 0-300 cm/s (4120.8xM) for water (approx. 0-30 cm/s up to 0-300 cm/s for oil, 4121.8xM).

At the maximum flow rate, adjust the range pot, until all nine LED's are just lit, each LED that is lit then represents approx. 10% of the maximum flow rate.

The resolution of the set-point depends on the range adjustment, e.g. with a range of 0-2 m/s the resolution is approx. 20 cm/s per LED step, with 0-30 cm/s the resolution is approx. 3 cm/s per LED step. When exceeding the adjusted measuring range by 10% the 9th LED is flashing with the double frequency of the set-point LED.

- LED flashing
- LED on
- LED off




example

7.0 Set-Point Adjustment

The set-point can be adjusted to anywhere within 15% of the absolute minimum range and 90% of the absolute maximum range.

Note: the 9th LED has no set-point related flashing function. If the 9th LED is flashing it indicates a flow higher than the adjusted max.

The set-point value is indicated by a flashing LED, and is shown relative to the adjusted range. When the velocity passes the flow set-point, the green "Flow OK" LED changes state (the green LED is lit if the velocity is above the set-point).



8.0 Response

The flow-captor offers the opportunity - in conjunction with the range and set-point selection - to adjust different response times. Since the signal is formed as an average flow fluctuations in the respective range will be largely suppressed.

